


CTH137

Exploded parts diagram

Image shown is CTH137







Number	Description	Qty
1	Feet (Left)	2
2	Feet (Right)	2
3	Bottom Board	1
4	Bottom Frame	2
5	Heater Tray	1
6	Heating Element	1
7	Heater Bracket	1
8	Panel Fascia (Front)	1
9	Heater Clamp	1
10	Ventilated Cover	1
11	Back Panel	1
12	Door Hinge	2
13	Door Glass	2
14	Door Frame	2
15	Front Pillar	2
16	Door Handle	2
17	Magnetic Strip	4
18	Side Glass	2
19	Fixing plate (Bottom)	1
20	Magnets	2
21	Top Panel	1
22	Control Panel	1
23	Top Cover	1
24	Transparent Lamp Cover	1
25	Fixing Plate for Lamp Cover	1
26	Thermometer	1
27	Fixing Plate (Top)	1
28	Transparent Plate	1
29	Thermostat Assy (Knob, fixed ring, thermostat)	1
30		
31		
32	Logo Plate	1
33	Switch	1
34	Indicator Light	1
35	Lamp Holder	1
36	Lamp Bracket	1
37	Electronic Ballast	1
38	Fluorescent Lamp	1
39	Socket Connector	1
40	Socket	1
41	Back Pillar	2
42	Thermostat	1
43	Thermostat	1
44	Power Cord	1
45	Plug Clamp	1

46	Decorative Strip	1
47	Curved Glass	1
48	Shelf Clamp	8
49	Shelf	3
50	Probe Clip	2
51	Water Tank	1

***** Please contact Spares for assistance *****