


HOTTOPI

Exploded parts diagram







Part Number	Number	Description	Qty
***	1	Power Cord	1
***	2	Stainless Housing	1
***	3	Heater Brace	1
***	4	Heater Chassis	1
B4-HEATER02	5	Heating Element	1
***	6	Bottom Plate	1
***	7	Ventilated Panel	1
***	8	Door Track	1
***	9	Bottom Shelf	1
***	10	Middle Shelf	1
***	11	Top Shelf	1
B4-LAMP04	12	LED	1
***	13	Door Track	1
***	14	Front Glass Bracket	1
***	15	Canopy	1
***	16	Light Cover	1
***	17	Top Glass Slide Bracket	1
***	18	Front Glass	1
***	19	Top Glass	1
B4-GLASS/SIDE03	20	Side Glass	2
***	22	Left Pillar	1
***	23	Right Pillar	1
***	24	Door Handle	2
B4-DOORHOT1	25	Door Glass	2
***	26	Door Roller Bracket	2
***	27	Roller	4
***	28	Right Panel	1
***	29	Left Panel	1
***	30	Probe Clip	1
***	31	1/9 GN Pan	1
B4-STAT06	32	Temperature Display	1
***	33	Feet	4
***	34	RH Light Cover	1
***	35	LH Light Cover	1
***	36	RH Top Shelf Bracket	1
***	37	LH Top Shelf Bracket	1
***	38	RH Bottom Bracket	1
***	39	LH Bottom Bracket	1
***	40	RH Bottom Bracket (small)	1
***	41	LH Bottom Bracket (Small)	1
***	42	Indicator Lamp	1
B4-SWITCH01	43	ON/OFF Switch	1

B4-THERM01	44.1	Thermostat	1
	44.2		
	44.3		
	44.4		
***	45.1	Gasket	8
***	45.2	Nut Gasket	8
***	45.3	Decorative Cover	8
***	46	Power Cord Socket	1
B4-STAT05	47	125 Deg. C Stat	1
B4-STAT04	48	150 Deg. C Stat	1
***	49	Control Panel	1

*** Please contact Spares for assistance ***